

Instruction Sheet

Product:
Switch Panel



Switch Panel Installation Instructions

- Middle Red wire to battery post on remote solenoid or starter
- Outside Red wire to starter post on solenoid
- Black wire goes to Small red wire on MSD style boxes, **OR** BAT terminal on HEI ignitions
- White wire goes from top of accessory switch (when used) to accessory